



DESK TO FLOOR

ASSEMBLE BASE BRACKET 1 TO POWER POLE, WITH SCREW 4 & HEX BOLT 5

FIX BRACKET 2 TO UNDERSIDE OF DESK, WITH SCREWS 3

FIX POWER POLE TO BRACKET 2 WITH SCREW 4 & HEX BOLT 5

FIX POWER POLE TO FLOOR, THROUGH BRACKET 1, USING SCREWS 3

CEILING TO DESK

CUT HOLE INTO CEILING TILE AND FIX GROMMET 6

FIX BRACKET 1 TO POWER POLE WITH SCREW 4 AND HEX BOLT 5

SLIDE POWER POLE INTO CEILING GROMMET 6

FIX POWER POLE TO DESK THROUGH BRACKET 1 WITH SCREWS 3

CEILING TO FLOOR

CUT HOLE INTO CEILING TILE AND FIX GROMMET 6

FIX BRACKET 1 TO POWER POLE WITH SCREW 4 AND HEX BOLT 5

SLIDE POWER POLE INTO CEILING GROMMET 6

FIX POWER POLE TO FLOOR THROUGH BRACKET 1 WITH SCREWS 3

CEILING THROUGH DESK

CUT HOLE INTO CEILING TILE AND FIX GROMMET 6

CUT HOLE INTO DESK AND FIX GROMMET 7

FIX BRACKET 1 TO POWER POLE WITH SCREW 4 AND HEX BOLT 5

SLIDE POWER POLE INTO CEILING GROMMET 6

SLIDE POWER POLE THROUGH IN-DESK GROMMET