

Titan Screed Box Installation



1. CUT SLAB



2. FIT SCREED BOX



3. RUN CABLES, WIRE GPO'S AND
TERMINATE DATA CONNECTIONS



4. SEAL CABLE TRUNKING, READY TO
INSTALL FLOORING



5. INSTALL FLOORING AND MAKE CUT-OUT
FOR FLOORBOX LID



6. SCREW FIX FLOORBOX LID AND INSERT
FLOORING INFILL TO COMPLETE INSTALL