USB DESK HOUSING Installation Instruction

STEP 2- FIT USB C HEAD INTO HOUSING A

STEP 1- INSERT USB C LEAD INTO DESK FROM UNDERSIDE

DESK OR FASCIA CUTOUT 19MM -0/+0.5 HOLE

STEP 3- CLIP HOUSING A AND B TOGETHER

CUTOUT 19MM -0/+0.5

STEP 4- INSERT AND ALIGN HOUSING TO COMPLETE

STEP 5- PLUG 12PIN LEAD INTO USB CHARGER