





CMS INSTALLATION GUIDE

SCREED BOX APPLICATION - FT3


STEP 1 -
LEVEL AND ANCHOR SCREED BOX
USING WIRE OR SCREWS TO PREVENT
MOVEMENT DURING CONCRETE POUR.
POSITION TO ENSURE TOP OF BOX IS FLUSH
WITH FINISHED LEVEL OF CONCRETE



INSTALL CONDUITS THROUGH 25mm KNOCKOUTS
AND RUN ELECTRICAL CABLES INTO SCREED BOX




CONDUIT LOCATIONS FT3CH SCREEDBOX



STEP 2 -
REMOVE TEMPORARY SCREEDBOX
COVER AND INSTALL THE UNDERCARRIAGE
USING THE SCREWS PROVIDED

STEP 3 -
TERMINATE ALL GPO DATA AND AV
OUTLETS INTO THE MOUNTING PLATES
AND INSTALL TO THE UNDERCARRIAGE
USING THE SCREWS PROVIDED.



STEP 4 -
LAY CARPET AND CUT OUT HOLE FOR
THE LID TO FIT- USE CUT PEICE TO INSTALL
INTO RECESS (IF APPLICABLE)
INSTALL AND SECURE THE LID FRAME
TO THE FLOORBOX UNDERCARRIAGE
USING THE FIXING SCREWS PROVIDED

NOTE: THE LID IS ADJUSTABLE TO ACCOMODATE
VARYING CARPET THICKNESS

